

Time Clock Operation

POWER UP

Turn on the power switch on the right hand side. You will be asked if you want to start where you left off. Press **NO** Then it will ask you if you want to use auto program. Press **YES** and then press **1**. The clock should be at 20:00 and then period set to 1
DO NOT TURN THE CLOCK OFF DURING A GAME!

TO SET THE MAIN TIME

Press **SET TIME** then 20:00 (or 15:00) then **YES**. When it says **PERIOD**, press 1, 2 or 3. To reset the time for the next period repeat the procedure.

TO SET A SCORE

Press **SET** then **HOME SCORE** (or **GUEST SCORE**) then the desired number. Note: you can also press **HOME SCORE....**the display will show + and then enter 1. The 1 will be added to the existing score.

TO SET A PENALTY

Press **SET** then **HOME** or **GUEST PNLTY**
Enter the **TIME** (e.g. 2:00 or 4:00) then press **YES**
When prompted for the **PLAYER** enter a two digit number (e.g 14,37,07)
The penalty will then be displayed on the clock

TO CLEAR A PENALTY

IF A GOAL IS SCORED (OR IF YOU ENTER INCORRECTLY)

Press **HOME** or **GUEST PENALTY** then **PNLTY CLEAR** it will display the penalty and ask you to enter **Y** or **N**

TO SET SHOTS ON GOAL

Press **HOME** or **GUEST PENALTY** and the display will show **SHOTS +**
Press a **1** to increment the shots by 1,
If you make a mistake and have to reset the shots then press **SET** followed by **HOME/GUEST SHOTS** and enter the correct number.

TO EDIT A PENALTY

Press **HOME** or **GUEST PNLTY** then **EDIT PNLTY**. The first penalty will be displayed and you will be asked if this is the penalty to edit. Enter **Y** or **N** and then the correct time.

MULTIPLE and DELAYED PENALTIES

Enter all penalties (except coincidental) into the clock for the appropriate team. The computer will keep track of delayed penalties and won't start a third penalty until the first penalty is cleared (due to a goal) or one expires.